



EURO SECURE

SECURING HOMES SINCE 2008



How to fit a Euro Cylinder

In the edge of the door there will be a fitting screw, this needs to be taken out and put to one side.

If you are unable to access the fitting screw (possible in a french door application) then it is wise to consult a qualified locksmith.

To remove or insert a euro-cylinder the key must be turned slightly to line the tongue of the central cam up with the body of the lock, this will enable the cylinder lock to slide in or out.

Getting the amount of key turn may require a bit of trial and error, but usually it requires a 15 to 20 degree turn either to the left or right, this is shown clearly on the video.

If there is any resistance to removing the cylinder it can help to just loosen the handle screws - sometimes a slightly offset handle can put pressure on the cylinder making it a little stiffer.